

# AC30 Radio Errata

The caution on the third line under “Listening to a Radio Broadcast” will be changed as shown below.

## Errata:

▲ When using the alarm to listen to the radio, leave the radio power switch in the STANDBY position. If the radio is turned off, move the power switch to the ON position, then to the STANDBY position.

## Correct:

▲ When the alarm is used to turn on the radio, the radio will automatically turn off after about 1 minute if the radio power switch is left in the STANDBY position. To turn off the radio immediately, press the ▲ or ▼ button. To continue listening to the radio, move the radio power switch to the ON position.

## 誤記訂正

「ラジオ放送を聞く」の3行目からの注意文を訂正します。

### 誤:

▲ アラームを使ってラジオにすると、ラジオ電源スイッチはSTANDBYの位置のままです。ラジオの電源を切るときは、一度スイッチをONの位置にしてから、STANDBYの位置にしてください。

### 正:

▲ アラームを使ってラジオにすると、ラジオ電源スイッチがSTANDBYの位置のままの場合、約1分後にラジオがオフになります。また、すぐにオフにしたい場合は、▲または▼ボタンを押してください。  
ラジオを続けて聴く場合は、ラジオ電源スイッチをONの位置にしてください。

AC30 Radio\_ERATTA1 EJ 1



**Vox Amplification Ltd.**

1 Harrison Close, Knowlhill, Milton Keynes, MK5 8PA. UK

[www.voxamps.com](http://www.voxamps.com)