

VOX Dynamic Looper Program List

PROG No.	PRE FX		LOOP FX		LOOP FX CATEGORY ★
	PRE FX TYPE	EDIT	LOOP FX TYPE	EDIT	
P01	# PEDAL	Od (Overdrive)	DELAY	3-16	INTRODUCTORY
P02	MOD	Ch2 (Chorus2)	# REVERSE	Fad (Crossfade)	
P03	BASS	Eb2 (Elec.Bass2)	# MOD	4-1	
P04	ACOUSTIC	S-1 (Small-1)	# VOLUME	Cur (Current Loop)	
P05	# PEDAL	dSt (Distortion)	LOOP IN LOOP	1-2	
P06	DELAY	dL2 (Clean2 tempo-sync)	# FILTER	bPF (Band Pass Filter)	
P07	REVERB	HAL (Hall)	# SPEED	SL2 (Slow2)	
P08	# WAH	Crn (Crunch)	SCRUB	0.0	
P09	PITCH	+12	# MOD	1-1	
P10	# SCI-FI	dr3 (Drone3)	X-FADE	In,L (Input-Loop)	
P11	# PEDAL	Crn (Crunch)	DELAY	1-16	BASIC
P12	MOD	PHA (Phaser)	# FILTER	HPF (High Pass Filter)	
P13	BASS	Eb1 (Elec.Bass1)	# VOLUME	ALL (Input & Loop1,2)	
P14	ACOUSTIC	S-2 (Small-2)	# REVERSE	Fad (Crossfade)	
◆ P15	EQ	HF (High Freq)	# MOD	8-1	
P16	DELAY	tP2 (Tape2 tempo-sync)	# PITCH	u35	
P17	REVERB	roo (Room)	# DELAY	1-8	
P18	# PEDAL	Od (Overdrive)	X-FADE	In,L (Input-Loop)	
P19	# STUTTER	1-8	FILTER	LP2 (Low Pass Filter 2)	
P20	SCI-FI	Sy2 (Synth2)	# PITCH	u24	
P21	PEDAL	dSt (Distortion)	# LOOP IN LOOP	1-16	TEMPO SYNC
P22	MOD	FLA (Flanger)	# DELAY	3-16	
P23	BASS	Eb3 (Elec.Bass3)	# MOD	1-4	
P24	ACOUSTIC	Lrg (Large)	# STUTTER	1-16	
◆ P25	EQ	HF (High Freq)	# LOOP IN LOOP	bAr	
P26	DELAY	An1 (Analog 1)	# MOD	2-1	
P27	REVERB	SPr (Spring)	# DELAY	3-8	
P28	# WAH	Crn (Crunch)	STUTTER	1-8	
P29	# STUTTER	1-16	MOD	1-1	
P30	SCI-FI	dr1 (Drone1)	# LOOP IN LOOP	1-4	
P31	# PEDAL	Cln (Clean)	DELAY	1-6	MIC
P32	MOD	Ch1 (Chorus1)	# LOOP IN LOOP	3-8	
P33	BASS	Eb4 (Elec.Bass4)	# MOD	1-16	
P34	ACOUSTIC	rES (Resonator)	# STUTTER	1-32	
◆ P35	EQ	CF (Mid Freq1)	# DELAY	1-16	
◆ P36	DELAY	dL1 (Clean1)	# REVERSE	Fad (Crossfade)	
◆ P37	REVERB	HAL (Hall)	# DELAY	1-4	
◆ P38	MOD	Ch1 (Chorus1)	# VOLUME	Cur (Current Loop)	
◆ P39	STUTTER	1-24	# FILTER	bPF (Band Pass Filter)	
◆ P40	PITCH	+12	# LOOP IN LOOP	1-32	
P41	# PEDAL	Co (Comp)	SPEED	SL1 (Slow1)	SCI-FI
P42	MOD	trE (Tremolo)	# PITCH	d24	
P43	BASS	Sb1 (Synth Bass1)	# LOOP IN LOOP	1-16	
P44	BASS	Sb2 (Synth Bass2)	# SPEED	FA1 (Fast1)	
◆ P45	EQ	HC (High Cut)	# SCRUB	1.8	
P46	DELAY	Sho (Short)	# PITCH	ubn	
P47	PITCH	-12	# SPEED	SL2 (Slow2)	
P48	# WAH	Od (Overdrive)	PITCH	u35	
P49	SCI-FI	dr2 (Drone2)	# SPEED	SF1 (Slow-Fast1)	
P50	SCI-FI	Slo (Slow Attack)	# SCRUB	10.0	

◆: Indicates presets with the PRE FX applied to both the Guitar INPUT and the MIC INPUT.

#: Indicates the primary function of the control pedal.

★: The Loop Effects Presets are organized into 5 categories to make the navigation of the pedal easier.

INTRODUCTORY: These effects will give you a quick overview of the diverse capabilities of the Dynamic Looper. (P01 to P10)

BASIC: These are effects that will be familiar to most musicians such as volume, filter and delays. (P11 to P20)

TEMPO SYNC: These are effects that can be synchronized using the TAP TEMPO or METRONOME functions. (P21 to P35)

MIC: These effects are designed for use with both the Guitar INPUT and the MIC INPUT. (P36 to P40)

SCI-FI: These effects are designed to make use of the strong processing power of the Dynamic Looper. SCI-FI effects will allow you to control loops and phrases in new ways creating sounds that were never before possible. (P41 to P50)

