




## How to Update the VOX Continental Operating System

This download contains a file named "VoxContinental\_v1\_0\_1.pkg". Please copy this file from your computer onto the root of a FAT32-formatted USB storage device and follow the procedure below.

*Note: USB storage devices, such as MS-DOS FAT16 or FAT32-formatted flash media or disks can be used. Other formats, including NTFS (Windows) or HFS+ (Mac OS X), will not work. Most USB flash drives use FAT32 by default.*

### Installing the new Operating System:


- 1) Plug the USB storage device containing the "VoxContinental\_v1\_0\_1.pkg" file into the USB-A port of the VOX Continental.
- 2) While holding down the VALVE DRIVE button and Type (CX-3/VOX/COMPACT) button in the ORGAN section, turn the VOX Continental's power ON.
- 3) The displays will read "uP", after a while "01." "0" "0." "01.", and "uP" again. Then, the system will begin updating automatically.



**DO NOT TURN OFF THE POWER WHILE THE SYSTEM IS UPDATING. DOING SO MAY CAUSE SERIOUS DAMAGE TO THE INSTRUMENT.**

*Note: If "01." "0" "0." "01" is not displayed, please ensure that the "VoxContinental\_v1\_0\_1.pkg" file is copied correctly on the root (top level; not within a folder) of the USB storage device, and repeat the steps. If the error persists, please try reformatting the USB storage device or try a different USB storage device.*

- 4) When the update is finished, the display will read "donE".



- 5) Please turn the power off, and then on again.


### Updating the Scene data:

Installing the Operation System does NOT update the preload Scene data automatically. Please update it manually by following these steps.



*Note: This will reset (initialize) the scene data and system setting data. Any edited or newly created favorite data will be overwritten, and your data will be lost. If you want to keep your scene data, save the data to a USB storage device. All system settings (including calibration data) will be reset, and you will need to make your settings and perform calibration once more.*


- 1) While holding down the EXIT button and E.PIANO button, turn the VOX Continental's power ON.
- 2) The display will read "rst". After about five seconds, the display and WRITE button will slowly blink.



- 3) Press the WRITE button.

*Note: Press any buttons except the WRITE button to cancel the reset operation.*

- 4) When the reset is completed, the display will read and blink "cnp", and after several seconds the VOX Continental will be able to be played normally.



The preload scenes are shown in the Scene List, found in the "VOX Continental Voice Name List".  
Download this manual at [www.voxamps.com](http://www.voxamps.com).