

Changes Since VOX Continental System Version 1.0.0

General

Changes

The USB Product ID has been updated. To connect the Vox Continental to your Mac or Windows computer, please download and install the latest version of the KORG USB-MIDI driver. The driver is available from the Korg website:
<http://www.korg.com>

Improvements

Various small improvements have been made to the sound data.

Bug fixes

In rare cases, switching sounds might have caused audio glitches. This has now been fixed.

Panel Operation

Improvements

Tracking accuracy has been improved when changing sounds very quickly by pressing the Type and Variation buttons.

In rare cases, pressing the EFFECT or EFFECT TYPE buttons might have caused the system to be silent until a new Scene was selected. This has now been fixed.

In rare cases, if the damper pedal was operated during the power-on process, the system would not start. This has now been fixed.

MIDI

Improvements

After receiving MIDI CC#11 Expression messages, the system resets the Expression value at Scene changes and/or Effect On/Off operations. This reset mechanism has been improved.

Bug fixes

When CC#67 (Soft Pedal) was turned on via MIDI, low velocity notes might have sounded incorrectly. This has now been fixed.

In addition to those listed above, various other minor improvements and bug fixes are also included in this update.