

VX II System Firmware Update

Update Procedures for Windows users


-  This updater is compatible with Windows 7 SP1 or later.
-  When other USB-MIDI devices are connected to your PC, the updater may not start correctly.
Please remove the other USB-MIDI devices from your PC.
-  Do not operate the VX II or the computer during the update process.

1. Unzip the “VXII_V####_win.zip”. (#### is version number)

-  Extract all the files in the zip file before proceeding to step 3.
The updater may not be able to find necessary files if they were not unzipped.


2. Turn the VX II on (by holding down the power switch) and connect to your PC via USB.

3. Execute the “VoxSystemUpdater.exe”. The following window will appear.
(This image is of the updater window when the VX II version is at 1.00.)




4. Push the [update] button in the window to start the process.

-  If “This version is already installed.” message is shown, the system firmware is already up to date. In this case simply quit the VOX System Updater. (Push the [exit] button in the window.)




-  The updater cannot recognize the VX II if step 3 is not done in the right order. Refer to the following list (“VOX System Updater Message List”).

5. During the updating process, the following window will appear.



-  Do not disconnect the VX II from the computer or turn off the power to the VX II during the update process.

6. The following message will be shown when the update has successfully completed.



7. Push the [exit] button in the window to quit the VOX System Updater.

8. Reboot the VX II.

-  You need to reboot the VX II to use the updated system.

Note: Due to this updater will update only the subsystem and not change the version number of the main system, the “Target” version information shown in “About” menu item of Tone Room will remain the same version number “1.00”.

VOX System Updater Message List

Communication Error (E**) [**:01~07]

Solution:

- Confirm if there is a **.vsb file corresponding to your device in the same folder where VoxSystemUpdater.exe is.
- Connect only the device which you would like to update to your PC/Mac.
Install VOX USB MIDI Driver (if not yet installed).
- Power the device off and reboot it.
(Switch the device into version up mode if the device has this function.)
Connect the device to your PC/Mac with a USB cable and restart the updater and execute the update process.

Failed to update!

Solution:

- Power the device off and reboot it.
(Switch the device into version up mode if the device has this function.)
Connect the device to your PC/Mac with a USB cable and restart the updater and execute the update process.